



Product data sheet

Product Code: UTCAR01

Product Name: Shesto Ultrasonic Cleaner Solution For Carburettor, Machine and Engine Parts

Product details: A concentrated ultrasonic Cleaner fluid designed in the UK to clean carburettors and engine parts, also machine parts and metal units.

Features & Benefits:

- A specialist formulation for adding to Ultrasonic baths for cleaning engine parts including carburetors, valves, heat exchangers etc
- It safely removes contaminants including general soiling, carbon and grease etc
- The cleaning process will not damage, corrode or darken metal components. Safe on brass, aluminium and other sensitive metals
- The concentrate solution is added to water at a rate of 1 part concentrate to 10 parts of water (we recommend using deionised / de-mineralized water)
- Operating temperature of bath should be set between 50 - 80 degrees centigrade
- Always test before use on new applications
- After cleaning rinse all surfaces thoroughly with clean water. The bath should be changed regularly when the solution becomes dirty
- Deep clean - Ideal for stain removal and removing dirt and oxidation
- Safe to use on most metals, although please test before use
- Designed for industrial professional use and hobbyist use